

READ!!

The carb adapter is made to fit a 1" Tillotson carb to a stock Mc91 intake and reed assembly. You need to remove existing studs, drill and tap the 2 vertical holes on the manifold to 1/4-20.

CAUTION!! You must make sure there is clearance between the bolt heads and the carb stack before tightening down the carb. Some carbs have more room than others, and you will need to make sure there is some visual clearance between the 2 parts. Leave the lock washers out if necessary

The studs on this adapter plate are special pressed-in studs with a head on them. They do not thread out. If you mess up the threads, you will need to send the plate back to us for repair at no cost. The epoxy on the back of the plate is necessary to seal the gasket surface properly.

This will not work with a small flatback carb without additional machining. Contact us.