

Read!!!

New for 2018! The carb adapter plate now fits a small Mac flatback or HL series Tillotson carb to a stock Mc91 intake and reed assembly. You need to remove existing studs, drill and tap the 2 vertical holes on the manifold to ¼-20.

Verify that the gasket pulse holes are lined up and unrestricted. Some Tilly base gaskets will not work on a flatback carb because the pulse opening is huge compared to a Tillotson.

The studs on this adapter plate are special pressed-in studs with a head on them. They do not thread out. If you mess up the threads, you will need to send the plate back to us for repair at no cost. The epoxy on the back of the plate is necessary to seal the gasket surface properly.

We recommend using a thin gasket sealer like GasketCinch or Coppercoat on all 3 gaskets. Make sure you don't get any in the pulse hole circuit!

Rev 6-2018